


How Tec4 Fuel Treatments Work



1. Cleans and lubricates the fuel pump.
2. Cleans fuel injector ensuring efficient fuel delivery.
3. Removes contamination build up on inlet valve seat and stem.
4. Removes contamination from piston ring grooves restoring lost compression.
5. Removes contamination from exhaust valve seat and stem ensuring efficient sealing of the combustion chamber.
6. Removes contamination from the EGR valve ensuring it works effectively.
7. Keeps the lambda sensor clean ensuring the correct reading is sent to the ECU.